alcatel

POP4
PLUS

QUICK START GUIDE

5056X
5056D

Removing or installing the back cover.

Charging the battery.



1. Inserting or removing the microSD card.
2. Installing or removing the SIM card (only for 5056D).
3. Installing or removing the SIM card.

User guide and FAQ are available online
www.alcatel-mobile.com

SAVE PAPER SAVE TREES

PLEASE CONSIDER THE ENVIRONMENT BEFORE PRINTING

English - CJB1F5002AAA